Technical Info

AP 3G / 4G cameras

Resetting the 3G / 4G (LTE) connection settings to factory defaults

1. PC or mobile phones with the local camera network connect standard network password is 1234567890

2. Open the browser on your PC or mobile phones. In the input field of the browser enter the IP address 192.168.100.1


3. Set the login window the language setting the top right of "English" and then to enter the password (default is "admin") to enter to the setup menu for the Wi-Fi and 3G / 4G settings

4. In the main menu with the 3G / 4G data connection, press the "Advanced Settings" setting.

5. Click the menu item "Others" in the Advanced Settings menu. After that, the menu setting "Reset Factory Settings" will appear. Please click on the setting

6. Answer the on-screen prompt with Yes. The camera resets the settings and reboots. It takes 2-3 minutes to the camera back is available.